



1. INSTALLATION

AIR INTAKE / FLUE EXHAUST Ø 3" (80 mm) ADAPTORS WITH PP TEST POINT (cod.: 65-00433)

These adapters are to be installed on co-linear vent (two separate pipes for exhaust and combustion air), and single exhaust vent (using room air for combustion). Additional bushings or couplings are required to transition from 3" schedule 40 pipe to 2" or 4" schedule 40 pipe only for installations using 2" or 4" schedule 40 pipe. Additional transition adapters are not needed for installations using only 60 mm or 80 mm polypropylene, or 3" schedule 40 PVC or CPVC pipe.

Ensure that the adapters are installed correctly into the correct locations as per the attached figure 1.

Installation instructions:

- Remove the air intake cover plate.
- Clean the inspection collar surface and the area of the air intake hole.
- Stick the appropriate neoprene gaskets onto the underside of the mounting flange of the adapters. Pay attention to aligning the four mounting through holes.
- Mount the intake/flue exhaust adapters with self tapping screws provided with the flue kit.
- Install the first piece of 60 mm or 80 mm polypropylene or 3" schedule 40 PVC or CPVC pipe until it bottoms out.
- Finally use the gear clamp to tighten the first piece of pipe to the adaptor.

